


Operation Manual and Parts Book

Wessex 3.0 Ton Trailer



Product Code: L2031



CONTENTS

| Welcome to your new Wessex Product |
|---|
| Safety Decals |
| Important Safety Warnings4 |
| Warranty |
| Operating Instructions / Using your Trailer / Maintenance |
| Specifications |
| Parts Illustration - Mainframe Assembly8 |
| Parts List - Mainframe Assembly9 |
| Parts Illustration / Parts List - Extension Side Set |
| CE Certificate |

WELCOME TO YOUR NEW WESSEX PRODUCT

Thank you for purchasing a Wessex product. As a Wessex customer, you now number among the most important people of our business and we will endeavour to give you the best service available through our dealer network.

Please read this Manual carefully and familiarise yourself and other persons that will be using the machine with its contents, to ensure the optimum performance and working life of your machine. It is advisable that a copy of this Manual is kept in the workshop and one copy with the machine. Further copies are available through your dealer.

On delivery, your dealer should go through the workings of the machine with you, explaining the setting up procedures, all of which are contained in this manual for further reference. The Warranty Registration Form must also be completed and returned to us **within 7 days of delivery** in order to validate the Warranty.

PLEASE READ THE FOLLOWING PAGES CAREFULLY BEFORE USING YOUR MACHINE AND KEEP THIS MANUAL IN A SAFE PLACE.



THIS SAFETY SYMBOL IS TO ALERT OPERATORS OF A HAZARD THAT MAY RESULT IN INJURY.

ALWAYS FOLLOW INSTRUCTIONS CAREFULLY

SAFETY DECALS



GB **ATTENTION** Description of pictograms.

F **ATTENTION** Description des pictogrames.

D **VORSICH** Beschreigung der piktogramme.



GB Read Operating manual before use.

F Lisez Manual D'Opéreration avant l'utilisation.

D Vor der Benutzung, Betriebshandbuch lesen.



GB Remove Tractors Bottom Link Arms before use.

F Retirer les armes Tracteurs lien du bas avant de l'utiliser.

D Entfernen Traktoren unteren Link Arms vor dem Gebrauch.



GB Keep clear of unproped body.

F Restez à l'écart du corps unproped.

D Halten Sie Abstand von unproped Körper.



GB Protective clothing must be worn.

F Vêtements de protection doivent être portés.

D Schutzkleidung getragen werden.



- 1. **ALWAYS** stand clear of unproped body.
- 2. **NEVER** tip body with people nearby, keep everybody (especially children and animals) at a safe distance.
- 3. **ALWAYS** remove Tractor bottom link arms while towing your Trailer from the pin hitch.
- 4. **NEVER** load your Trailer in excess of 3.0 Ton gross weight.
- 5. **NEVER** unhitch a loaded Trailer.
- 6. **NEVER** tow at above 30 kilometres per hour.
- 7. **ALWAYS** chock the wheels when parking the Trailer.
- 8. **NEVER** tip your trailer on sloping ground.

WARRANTY

Your Wessex product or equipment is warranted free from defect in workmanship or manufacture for one year from date of purchase. Any parts which appear to us to be defective, either in material or workmanship shall be replaced or repaired at no cost to the purchaser, subject to the following conditions:

- The registration card enclosed with this booklet must be returned to us within seven days of purchase.
- 2. Any failure in the machine should be reported in the first instance immediately to your dealer, who will act on your behalf to resolve the matter to your satisfaction.
- 3. The defective parts will be returned by your dealer to us, accompanied by a full statement describing the failure and the circumstances and conditions in which the failure occurred.
- 4. The following are specifically excluded from our terms of warranty:
 - a) Fair wear and tear, especially to belts, brushes, blades and spinners.
 - b) Damage to blades or brushes caused through incorrect positioning of the rotor (see instructions).
 - c) Damage caused by neglect or lack of lubrication.
 - d) Damage caused by misuse or abuse.
 - e) Damage caused whilst the machine is in transit.
 - f) Damage caused to the frame of the machine by running the machine with unbalanced rotors, blades or spinners.
 - g) Damage caused to the machine by use with loose nuts, bolts, screws or any other type of fittings.
- 5. The warranty is for the benefit of the first user only.
- 6. Wessex International decisions will be final and binding.

Note:

It is recommended that every machine is inspected after one hour of operation to check that all nuts, bolts, screws or any other types of fixings are tight and any loose fixings or components should be rectified as appropriate.

Further inspections should be carried out at regular intervals thereafter.

HITCHING UP YOUR WESSEX TRAILER

- 1. Remove the Tractor Bottom link arms.
- 2. Reverse the Tractor so that the Trailer drawbar is between the clevis on your Tractor, if need be altering the height of the Trailer drawbar by adjusting the screw jack
- 3. Secure with either a pickup hitch or a drawbar pin (not supplied) and retain with a linch pin.
- 4. Connect the hydraulic hose to Tractor tipping pipe.
- 5. Wind the parking jack into the fully raised position and turn until tight.

USING YOUR TRAILER

- 1. Take care not to turn the Tractor and Trailer on steep ground, especailly when heavily loaded.
- 2. When loading aggregates and soil with a fore loader, take care to lower the load as much as possible before releasing it into the Trailer.
- 3. Never park the Trailer with the body in the tipped position as this will cause corrosion to the Hydraulic ram.
- 4. The optional Extension Side Set is supplied purely for use with light loads such as leaves, loose grass clippings and hedge prunings etc.
- Never use the extension Side Set to increase the volume of aggregates and heavy material.
- 6. The Trailer rear corner posts, side boards and tailgate can be removed when loading bales etc.
- 7. When using your Tailer on the road always use the rear Lighting Kit and Parking Brake Assembly.

MAINTENANCE

- 1. Periodically grease wheel bearings.
- 2. Periodically grease hinge pins.
- 3. Regularly grease the parking jack.
- 4. Tyre pressure for standard Trailer and Trailer with parking brake 65 psi max.
- 5. Tyre pressure for flotation tyres 22 psi max.

SPECIFICATIONS

Maximum Gross Weight 3.0 Ton .


Length Excluding Drawbar (m) 2.45

Width (m) 1.5

Side Height (m) 0.38


Loading Height 0.61

Tyre Size 26 x 12.00 x 12



PARTS LIST - 3.0 TON TRAILER MAINFRAME ASSEMBLY - PLATE 1

| Item No. | Part No. | Description | Qty. per Machine |
|----------|-------------|----------------------------------|------------------|
| 1 | WX-17679 | Head Board | 1 |
| 2 | WX-0530 | Anti-Luce Lug | 4 |
| 3 | WX-17179 | Side Board (Left and Right Hand) | 2 |
| 4 | WX-14279/50 | Weld on Hinge Hook | 4 |
| 5 | WX-3703 | Hinge Hook Fastening Set | 1 |
| 6 | WX-18579 | Draw Bar | 1 |
| 7 | WX-0556 | Hose Assembly | 1 |
| 8 | WX-1901 | Fastening Set Jack Assembly | 1 |
| 9 | WX-0156 | Jack Assembly | 1 |
| 10 | WX-19601 | Fastening Set Draw Bar | 1 |
| 11 | WX-3202 | Fastening Set Ram | 1 |
| 12 | WX-0456 | Ram | 1 |
| 13 | WX-16679 | Main Chassis | 1 |
| 14 | WX-5653 | Hub | 2 |
| 15 | WX-2753 | Hub Cap | 2 |
| 16 | WX-3252 | Wheel Complete | 2 |
| 16 | WX-10151 | Tube | 2 |
| 16 | WX-10051 | Tyre | 2 |
| N/S | WX-3338 | Inner Bearing | 2 |
| N/S | WX-3438 | Outer Bearing | 2 |
| N/S | WX-0845 | Hub Oil Seal | 2 |
| 17L | WX-17779L | Left Hand Corner Post | 1 |
| 17R | WX-17779R | Right Hand Corner Post | 1 |
| 18 | WX-0730 | Forket C/W Cotter and Chain | 4 |
| 19 | WX-0630 | Tail Board Lug | 4 |
| 20 | WX-17579 | Tail Board | 1 |
| 21 | WX-16979 | Main Body | 1 |



PARTS LIST - EXTENSION SIDE SET - PLATE 2

| Item No. | Part No. | Description | Qty. per Machine |
|----------|-----------|------------------------|------------------|
| 1 | WX-18179 | Head Board Frame | 1 |
| 2 | WX-18079L | Left Hand Side Frame | 1 |
| 3 | WX-18079R | Right Hand Side Frame | 1 |
| 4 | WX-18279 | Tail Gate | 1 |
| 5 | WX-18279L | Left Hand Corner Post | 1 |
| 6 | WX-18279R | Right Hand Corner Post | 1 |
| 7 | WX-0730 | Cotter Pin and Chain | 4 |
| N/S | | Fixing Set Complete | 1 |



Certificate of CE Conformity

| Machine Model: | 3.0 Ton | | |
|----------------|---------------------------|--|--|
| | | | |
| Description: | Hydraulic Tipping Trailer | | |

I hereby certify that the machine detailed hereon conforms to:

European Directives 2008/42/EC Supply of Machinery Regulations 2008

As amended 91/368EEC - 93/44EEC - 93/68EEC

| | | _ | |
|-----------------|--|-------|-------------|
| Signed: | | Date: | August 2011 |
| Quality Manager | | [| |

 $\cap \cap$

Wessex International

Charlton House, Caxton Place, East Portway Industrial Estate, Andover, Hampshire SP10 3QN Telephone: 01264 345870 Fax: 01264 345 880

www.wessexintl.com



Wessex International
Charlton House, Caxton Close, East Portway Industrial Estate, Andover Hampshire. SP10 3QN
Telephone: 01264 345870 Fax 01264 345880
e-mail: sales@wessexintl.com

www.wessexintl.com