

Operation Manual

Wessex Country LR480 & LR600 Land Roller

Product Code: 2022



Contents

Welcome to your new Wessex Machine4
Safety Instructions5
Warranty7
Safety Decals8
Coupling up to your ATV / Tractor9
Maintenance10
Wessex CE Certificate11

WELCOME TO YOUR NEW WESSEX LR480/LR600 LAND ROLLER

Thank you for purchasing a Wessex Land Roller. As a Wessex customer, you now number among the most important people of our business and we will endeavour to give you the best service available through our dealer network.

Please read this Manual carefully and familiarise yourself and other persons that will be using the machine with its contents to ensure the optimum performance and working life of your machine. It is advisable that a copy of this Manual is kept in the workshop and one copy with the machine. Further copies are available through your dealer.

On delivery, your dealer should go through the workings of the machine with you, explaining the setting up procedures, all of which are contained in this manual for further reference. The Warranty Registration Form must also be completed and returned to us **within 7 days of delivery** in order to validate the Warranty.

PLEASE READ THE FOLLOWING PAGES CAREFULLY BEFORE USING YOUR MACHINE AND KEEP THIS MANUAL IN A SAFE PLACE.



THIS SAFETY SYMBOL IS TO ALERT OPERATORS OF A HAZARD THAT MAY RESULT IN INJURY.
ALWAYS FOLLOW INSTRUCTIONS CAREFULLY.

READ THE FOLLOWING CAREFULLY.

IMPORTANT SAFETY INSTRUCTIONS ON COUPLING IMPLEMENTS AND ATTACHMENTS TO ATV'S



Training

- It is most essential that all operators of ATV's are trained by a certified training organization.
- It is strictly forbidden that any person under 16 years of age should ride an ATV.
- Any person 17 years of age must have had training before towing a trailer with an ATV.
- Contact your local HSE office for approved training courses.

Body Protection

- Remember that when riding on a vehicle the only form of protection that you have is what you wear. ALWAYS
 wear a helmet, eye protection and suitable robust clothing.
- Never operate a vehicle or attachments while under the influence of alcohol or non-prescription drugs.
- Contact your doctor before operation of a vehicle or attachments while under the influence of any prescription drugs.

Vehicle Manual

Before coupling any implement to your vehicle refer to your vehicle handbook.

Stability

When using equipment coupled to an ATV it is very important to remember that the handling characteristics of
your ATV will change dramatically, whether the additional load is placed on the front or rear rack or trailed on the
towing ball hitch.

Weight Capacity

- Always ensure that the implement or attachment that you are coupling to the ATV is within the ATV's drawbar loading or weight carrying capacity. Refer to the vehicle manufacturer's handbook to obtain information on the specific capacities.
- It is most important that you know the weight of your load, especially when on slopes or hillsides.
- As a guide on level ground with an unbraked implement, the weight of the implement should be approximately no more than twice the un-laden weight of the vehicle. This should be reduced on sloping, uneven or rough ground.

Weight Transfer

- Always take great care when towing loads which may be subject to weight transfer e.g. liquids or livestock, especially on hillsides and slopes.
- Always restrict the movement of animals or rolling objects in a trailer.

Towing

- Never tow loads larger or heavier than recommended for your Vehicle. (See hand book)
- Never tow or turn across a slope.
- Never tow down a steep slope with a large or heavy load.
- When towing heavy loads there is a significant risk of jack-knifing or overturning.

Rough Terrain

- Always take care when operating implements on rough terrain or uneven ground.
- Take special care when operating on slippery surfaces especially hill sides or slopes.
- Take extra care when towing on hillsides, slopes or rough terrain.

Operating on roads

- Implements are not designed for travelling distances on roads but when crossing or going short road distances always travel slowly and do not exceed 20 KPH.
- Make sure that your equipment complies with Road vehicle lighting regulations.
- Ensure that you have the correct insurance cover and comply with all relevant laws.

Load Security

- Always secure your load firmly with ratchet straps.
- Make sure that your load is evenly distributed.
- Never stack a high load, high loads increase the risk of overturning.

Passengers

Never carry passengers on any kind of implement or attachment, especially children.

Maintenance

• Service your vehicle and attachments as per the manufacturer's handbook. Regular servicing of your vehicle will ensure that it will steer, stop and handle to its best ability and your attachment will operate as safely and effectively as possible. Regular servicing helps ensure the longest possible working life for your equipment.

Equipment Safety Inspection

- Check tyre pressure, incorrect tyre pressure can seriously affect the handling of your vehicle. (See Operators handbook)
- Maintain your equipment regularly to keep it in safe working order.

Route/Risk Assessment

- Assess and plan the route that you intend to travel to avoid any type of hazards i.e. rocks, boulders, ditches, hidden fences or wire, pot holes, low hanging branches or any other type of hazard.
- Where possible stay with a routine route to avoid hazards.
- The risk may change in wet or wintery conditions, avoid slopes where possible.

WARRANTY

Your Wessex product or equipment is warranted free from defect in workmanship or manufacture for one year from date of purchase. Any parts which appear to us to be defective, either in material or workmanship shall be replaced or repaired at no cost to the purchaser, subject to the following conditions:

- 1. The registration card enclosed with this booklet must be returned to us within seven days of purchase.
- 2. Any failure in the machine should be reported in the first instance immediately to your dealer, who will act on your behalf to resolve the matter to your satisfaction.
- 3. The defective parts will be returned by your dealer to us, accompanied by a full statement describing the failure and the circumstances and conditions in which the failure occurred.
- 4. The following are specifically excluded from our terms of warranty:
 - a) Fair wear and tear, especially to belts, brushes, blades and spinners.
 - b) Damage to blades or brushes caused through incorrect positioning of the rotor (see instructions)
 - c) Damage caused by neglect or lack of lubrication.
 - d) Damage caused by misuse or abuse.
 - e) Damage caused whilst the machine is in transit.
 - f) Damage caused to the frame of the machine by running the machine with unbalanced rotors, blades or spinners.
 - g) Damage caused to the machine by use with loose nuts, bolts, screws or any other type of fittings.
- 5. The warranty is for the benefit of the first user only.
- 6. Wessex International decisions will be final and binding.

NOTE:

It is recommended that every machine is inspected after one hour of operation to check that all nuts, bolts, screws or any other type of fixings are tight and any loose fittings or components should be rectified as appropriate.

Further inspections should be carried out at regular intervals thereafter.

SAFETY DECALS







GB Read operating manual before use.

| Confident | Confident

• F Lisez Manual D'Opération avant l'utilisation.

• D Vor der, Bentriebshandbuch lessen.



• GB Protective eyewear, footwear, gloves and ear protectors must be worn.

• F Des lunettes de protection, chaussures, gants, protèges-oreilles doivent être portés.

• D Schutzbrille, Schuhe, Handschuhe und Gehörschutz getragen werden.



• GB It is the operators responsibility to ensure that the machine is compatible with the loading capacity of the towing vehicle.

• F Il est de la responsabilité des opérateurs afin de s'assurer que la machine est compatible avec la capacité de chargement du véhicule tracteur.

• D Es ist den Betreibern dafür zu sorgen, dass die Maschine mit der Belastbarkeit des Zugfahrzeugs ist.



GB Never carry passengers on implements unless designed to do so.

• F Ne jamais transporter des passagers sur instruments sauf s'ils sont conçus pour le faire.

• D Niemals Passagiere implementiert, es sei denn ausgelegt, dies zu tun.

COUPLING UP TO YOUR ATV/TRACTOR

- A four wheel drive ATV is most suitable.
- Your Wessex Land Roller is not suitable for use with an ATV of less than 450cc capacity.
- Reverse your ATV/Tractor up to your roller and couple the ball hitch, ensure that the hitch is properly located.
- If extra weight is required simply undo the bung in the end of the roller drum, fill to the required weight with water and refit the bung.
- Adjust the scraper to approximately 3mm from the roller.



Before operating, ensure that the towing vehicle weight ratio is within HSE guidelines. See HSE leaflet AIS33. The weight ratio between the towing vehicle and the towed implement needs to be assessed carefully, especially if towing with an ATV. For an unbraked implement or trailer the maximum weight of the implement and load should not exceed twice the unladen weight of the ATV. When used on slopes or hill sides these weights should be reduced by 25% - 30% for stability.

The Wessex Land Roller is designed for use on grassland in paddocks and on mild or non-steep slopes.

Use on steep slopes could cause serious injury or death.

MAINTENANCE

Grease the main roller bearings and the ball hitch every 60 hours.

SPECIFICATION

Model	LR480	LR600
Width (m)	1.2	1.5
Empty Weight (kg)	170	200
Filled Weight (kg)	450	550
Drum Diameter (mm)	560	560

Other features:

Choice of ball or clevis hitch

Adjustable scraper bar



INTERNATIONAL Certificate of CE Conformity

Machine Model:	LR480 & LR600	
Description:	Land Roller	

I hereby certify that the machine detailed hereon

conforms to:

European Directives 2008/42/EC Supply of Machinery Regulations 2008

As amended 91/368EEC - 93/44EEC - 93/68EEC/HSE A1S 33

Signed: Date: 24/11/2010

Robert James



Wessex International

Charlton House, Caxton Close, East Portway Industrial Estate, Andover, Hampshire, SP10 3QN T: 01264 345870 F: 01264 345880 E: info@wessexintl.com



Wessex International
Charlton House, Caxton Close, East Portway Industrial Estate, Andover, Hampshire, SP10 3QN

Telephone: 01264 345870 Fax: 01264 345880

e-mail: sales@wessexintl.com

www.wessexintl.com